


Magnetic Tool Holder Instructions

1. Place L shaped piece, TR-HDL, in panel as shown in picture below. Remove the wing nut.
2. Slide Magnetic Tool Holder onto the TR-HDL as shown in picture below.
3. Screw on wing nut to secure the Magnetic Tool Holder in place.
4. Repeat for the other side of the Magnetic Tool Holder.

Step 1:



Step 2/3:

